



LEGEND:

1. Promat MASTERBOARD® 9mm thick
2. Rebate, 30mm wide, 2mm deep (creating a 60mm wide joint)
3. PVA sealer
4. Self-adhesive 50mm wide woven fibreglass jointing scrim
5. Promat Moisture Resistant Ready-Mixed Joint filler
6. Timber or steel stud support framework behind all board joints
7. Dry wall self-tapping screws or dry wall nails

Promat MASTERBOARD® is available with the option of rebated edges for 9mm thick boards

The rebating, which is machined along all 4 edges, enables seamless jointing of boards to be achieved.

Through simple taping and jointing of the shallow trough, formed by the butting of rebated boards, a smooth seamless joint is achieved which enhances and extends the aesthetic option for use in:

- Ceilings
- Partitions
- Roof linings

FLUSH JOINTING WITH MASTERBOARD® IS A SIMPLE THREE-STAGE PROCESS:

Preparation	Prior to joint filling the joint profile should be sealed with a PVA or universal sealer.
Filling the joint	Apply the fibreglass tape to the rebate and fill the trough with Promat Moisture Resistant Ready-Mixed Joint Filler.
Finishing	Finish with Promat Moisture Resistant Ready-Mixed Joint Filler.

Please note: To achieve optimum performance and aesthetics the following should be adhered to:

1. All nails and screws should be driven flush with the board.
2. Any gaps, greater than 2mm between the boards, should be completely filled with PROMAT Moisture Resistant Ready-Mixed Joint filler.

3. All installation recommendations (i.e. support centres, fixing methods etc.) contained within the PROMAT Fire Protection Handbook or the Promat MASTERBOARD brochure should be complied with.
4. All board joints must be backed by support framework.

AUTHORITY: PROMAT RECOMMENDATION

